Defaults 1: Programming Barcodes for LS2208



Configuration name in Utility :	Defaults 1
Last Modified :	09-4-18
Windows Filename :	Config File_LS2208_Defaults 1_2018.04.09.scncfg
Plug-in Name :	LS2208-COMMON MODELS v2.0-007

Instructions: Scan barcodes in order, starting with programming barcode 1.

1/4. Set Factory Defaults

Cable Connection Settings

USB

2/4. USB Device Type CDC

Modify Data

3/4. Suffix 1 : Enter,7,0,1,3,Scan Data Transmission Format <Data><Suffix 1>

General Parameter Settings

4/4. Configuration File Defaults 1

Firmware:

CAACFS00-002-R00

Supported Scanner Models for Plug-in :

LS2208-SR20001BR

LS2208-SR20001BR-K

LS2208-SR20001BR-R

Defaults 1: Programming Barcodes for LS2208



Configuration name in Utility :	Defaults 1
Last Modified :	09-4-18
Windows Filename :	Config File_LS2208_Defaults 1_2018.04.09.scncfg
Plug-in Name :	LS2208-COMMON MODELS v2.0-007

LS2208-SR20001BR-U

LS2208-SR20001BZ-K

LS2208-SR20001NA

LS2208-SR20001R

LS2208-SR20001R-KR

LS2208-SR20001R-NA

LS2208-SR20001R-UR

LS2208-SR20001Z-UR

LS2208-SR20007BR-K

LS2208-SR20007BR-R

LS2208-SR20007BR-U

LS2208-SR20007BZ-K

LS2208-SR20007NA

LS2208-SR20007R

LS2208-SR20007R-KR

LS2208-SR20007R-NA

LS2208-SR20007R-UR

LS2208-SR20007Y

LS2208-SR30001R

LS2208-SR30007R